



## ESTL 14/16/16T SERIES FORKOVER ELECTRIC STACKER

- Sideway battery exchange to reduce intervals, ensure working efficiency and productivity.
- Durable and rigid frame construction ensure the stackers to handle heavy loads.
- Limit switch mounted on top of mast to precisely set the max. Lifting height, avoid any risk of lifting motor overload.
- Safe Grid covered on the mast to protect operator from any injured risk.

Model		ESTL 14	ESTL 16	ESTL 16T
Lifting Capacity	Kg	1400	1600	1600
Load Center	mm	600		
Max. Lift Height	mm	3000/3300/3600/4000		4500/5000
Mast Lowered Height	mm	1980/2135/2335/2500		2135/2335
Fork Lowered Height	mm	85		
Turning Radius	mm	1975		2040
Travel Speed (loading/without loading)	km/h	3.5/3.5		
Gradeability (loading/without loading)	km/h	0.13/0.23		
Lifting Speed (loading/without loading)	%	5/7		
Battery (Lead-acid traction)	V/AH	24/280		
Driving Motor(AC)	KW	1.5		
Lifting Motor(DC)	KW	3		
Overall Length	mm	1995		2055
Overall Width	mm	1470		
Weight With Battery (3000mm)standard		1161	1251	1527
Controller		CURTIS 1230		
Steering		Power Steering		